

INSTALLATION INSTRUCTIONS

2017 CAN-AM

REAR BUMPER

1. FROM UNDERNEATH BED.REMOVE THE TWO BOLTS FROM THE PLASTIC MOUNTING BRACKET THAT HOLDS THE BED TO THE FRAME.
2. GENTLY LIFT UP ON THE BED TO REMOVE MOUNTING BRACKET.
3. INSTALL TOUGH COUNTRY BRACKET IN ITS PLACE.
4. ALIGN BOLT HOLES AND SET BED BACK DOWN.
5. INSTALL FACTORY HARDWARE BACK ONTO BOLTS AND LEAVE LOOSE.
6. REPEAT ON OPPOSITE SIDE.
7. INSTALL TOUGH COUNTRY BUMPER WITH THE SUPPLIED BOLTS AND HARDWARE .
8. ALIGN BUMPER MAKING SURE THE BUMPER DOES NOT HIT TAILGATE.
9. TIGHTEN ALL BOLTS TO SPEC.
10. IF NOT INSTALLING TOUGH COUNTRY LIGHTS INSTALL SUPPLIED COVER PLATES WITH SUPPLIED BOLTS.

Thank you for using Tough Country Products

