

HONDA 1000 2015-C

TOOLS REQUIRED:

13MM SOCKET
RATCHET
5/8 WRENCH

#5 ALLEN WRENCH
13MM WRENCH
11/16 WRENCH

REMOVAL OF BUMPER

- 1) REMOVE ALLEN BOLT ON SIDE OF THE FACTORY BUMPER HOLDING PLASTIC. REPEAT ON OPPOSITE SIDE
- 2) REMOVE THE TWO 13MM BOLTS ON THE BOTTOM OF THE BUMPER.
- 3) REMOVE THE TWO BOLTS ON EACH SIDE OF THE BUMPER. CAREFULLY REMOVE THE BUMPER AND SET ASIDE.

INSTALLING TOUGH COUNTRY BUMPER

- 1) INSTALL SPACERS INTO TOP PART OF FRAME.MAKING SURE THE TWO BOLTS CLEAR INSIDE OF SPACER.
- 2) INSTALL TOP BRACKETS ON OUTSIDE OF THE FRAME HAND TIGHT; WITH THE ANGLES FACING OUTWARD.
- 3) INSTALL TOUGH COUNTRY BUMPER ONTO THE TOP BRACKET WITH THE SUPPLIED 7/16 X 2 BOLTS AND HARDWARE; LEAVE LOOSE
- 4) ALIGN BOTTOM HOLES AND INSTALL BOLTS.
- 5) ALIGN BUMPER, TIGHTEN ALL BOLTS.

THANK YOU FOR CHOOSING TOUGH COUNTRY PRODUCTS