

INSTALLATION INSTRUCTIONS

POLARIS 900 & 800

2013-16 POLARIS REAR BUMPER

TOOLS NEEDED:

RATCHET

9/16" SOCKET

REAR BUMPER INSTALLATION:

1. SET BUMPER IN PLACE AND USE PROVIDED 5/16" X 1-1/4" CARRIAGE BOLTS INTO BUMPER MOUNTING TABS AND HAND TIGHTEN ONLY.
2. PICK UP BACKSIDE OF BUMPER AND USE PROVIDED 5/16" X 3" BOLTS TO SLIDE THROUGH PIPE SPACER IN BETWEEN EXISTING BRACKET, PUTTING BOLT IN FROM THE INSIDE OF BRACKET TOWARDS THE OUTSIDE AND HAND TIGHTEN ONLY.
3. PROPERLY ALIGN FOR APPEARANCE AND TIGHTEN ALL BOLTS SECURELY.

THANK YOU FOR CHOOSING TOUGH COUNTRY PRODUCTS